


## AD/AD Actuators



installation, operation &  
maintenance manual

# contents

|  |              |
|--|--------------|
| <b>Section 1 - Before You Start</b>              | <b>4</b>     |
| 1.1 Reference Documents                          | 4            |
| 1.2 Warehouse Storage                            | 4            |
| 1.2 On-Site Storage                              | 4            |
| <b>Section 2 - Introduction</b>                  | <b>6-7</b>   |
| 2.1 Identification                               | 6            |
| 2.2 Intended Usage                               | 6            |
| 2.2 Specifications                               | 6-7          |
| <b>Section 3 - Part Number Matrix</b>            | <b>8</b>     |
| <b>Section 4 - Installation</b>                  | <b>9-16</b>  |
| 4.1 Before You Start                             | 9            |
| 4.2 Actuator Rotation Direction                  | 9            |
| 4.2.1 Valve Rotation                             | 9            |
| 4.2.2 Position After Failure                     | 9            |
| 4.3 Principles of Operation                      | 10           |
| 4.3.1 Solenoid Valve                             | 10           |
| 4.3.2 Ingress Protection (IP) Rating             | 10           |
| 4.3.3 Double-Acting Actuators                    | 11           |
| 4.3.4 Spring-Return Actuators                    | 11           |
| 4.4 Actuator Assembly Codes                      | 12           |
| 4.5 Actuator to Valve Assembly                   | 13           |
| 4.6 Mounting of Control and Feedback Accessories | 16           |
| 4.7 Recommended Tubing Sizes                     | 16           |
| <b>Section 5 - Mechanical Stroke Adjustment</b>  | <b>17-19</b> |
| 5.1 Travel Stop Adjustments                      | 17           |
| 5.1.1 Double-Acting Actuators                    | 17           |
| 5.1.2 Spring-Return Actuators                    | 18           |
| 5.1.3 Angular Displacement                       | 19           |
| <b>Section 6 - Maintenance</b>                   | <b>20</b>    |
| 6.1 Normal Maintenance                           | 20           |
| 6.2 Inspection and Repair                        | 20           |
| 6.2.1 Service Kits                               | 20           |
| 6.2.2 Spring-Return Actuators                    | 20           |

|   |              |
|---|--------------|
| <b>Section 7 - Decommission (Out-of-Service)</b>  | <b>21</b>    |
| 7.1 Before You Start                              | 21           |
| 7.2 Removing the Actuator from the Valve          | 21           |
| <b>Section 8 - Disassembly</b>                    | <b>22-29</b> |
| 8.1 Removing End Caps (Sizes 0025-0600)           | 23-24        |
| 8.2 Removing End Caps (Sizes 0950-4000)           | 25           |
| 8.3 Removing Spring Cartridges or Springs         | 26           |
| 8.4 Removing Limit Stop Screws                    | 27           |
| 8.5 Removing Pistons                              | 27           |
| 8.6 Removing Pinions                              | 28           |
| 8.7 Cleaning the Components                       | 29           |
| <b>Section 9 - Reassembly</b>                     | <b>30-</b>   |
| 9.1 Grease Instructions                           | 31           |
| 9.2 Pinion Reassembly                             | 32           |
| 9.3 Piston Reassembly                             | 33-34        |
| 9.4 Limit Stop Screws Setting Reassembly          | 35           |
| 9.5 End Cap Reassembly                            | 36           |
| 9.5.1 Double-Acting Actuators                     | 36           |
| 9.5.2 Spring-Return Actuators (Sizes 0025-0600)   | 37-38        |
| 9.5.3 Spring-Return Actuators (Sizes 0950-4000)   | 39-40        |
| 9.6 Basic Function and Air Leak Test              | 41           |
| <b>Section 10 - Troubleshooting</b>               | <b>42-43</b> |
| 10.1 Mechanical Problems                          | 42           |
| 10.2 Pneumatic Problems                           | 43           |
| 10.3 Electrical Problems                          | 43           |
| <b>Section 11 - Parts Lists</b>                   | <b>44-47</b> |
| 11.1 Actuators Size 0012                          | 44           |
| 11.2 Actuators Sizes 0025-0600                    | 45           |
| 11.3 Actuators Sizes 0950-2500                    | 46           |
| 11.4 Actuators Sizes 4000                         | 47           |
| <b>Appendix A - Spring Load Removal</b>           | <b>48</b>    |
| A.1 Spring Load Relief                            | 48           |
| <b>Appendix B - Tool and Torque Tables</b>        | <b>49</b>    |
| <b>Appendix C - Full Stroke Adjustment</b>        | <b>50-54</b> |
| C.1 Full Stroke Adjustment Option                 | 50           |
| C.2 Convert Standard Actuator to Full Stroke      | 51           |
| C.2.1 Procedure                                   | 52           |
| C.3 Full Stroke Adjustment Setting                | 53           |
| C.3.1 Factory Setting Procedure                   | 53           |
| C.3.2 Setting the Required Adjustment Screw Angle | 54           |

This section explains:

- Base safety procedures.
- Where to find detailed information relating safety.
- Storage guidelines.

Installation, adjustment, putting into service, use, assembly, disassembly and maintenance of the pneumatic actuator must be performed by qualified personnel.

### **NOTE**

Failure to follow the above guidelines will void warranty.

### **⚠ CAUTION ⚠**

Actuator must be isolated both pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembly, the actuator consult the relevant sections of this manual.

## **1.1 INSTALLATION, OPERATION AND MAINTENANCE REFERENCE DOCUMENTS**

Before you start, read all chapters in this manual.

### **NOTE**

Failure to read the Safety Guide will void the warranty.

Not following the instructions of the Safety Guide can lead to failure of the product and harm to personnel or equipment.

## **1.2 WAREHOUSE STORAGE**

- All actuators should be stored in a clean, dry warehouse, free from excessive vibration and rapid temperature changes.
- All actuators should not be stored directly to the floor surface - it must be placed in racks/shelves or use a pallet.

## **1.3 ON-SITE STORAGE**

- All actuators should be stored in a clean, dry warehouse, free from excessive vibration and rapid temperature changes.
- Prevent moisture or dirt from entering the actuator. Plug or seal both air connection ports.


### **NOTE**

Failure to follow the above guidelines (Warehouse and On Site Storages) will void warranty.

### 2.1 IDENTIFICATION

- The Apollo Rack and Pinion actuators are available as double-acting or spring-return versions. 13 models are available, ranging from 12 Nm to 4000 Nm (106 to 35,000 lb.in) nominal torque output.
- The Apollo actuators use standardized interfaces for solenoid, switchbox or positioner mounting (VDI/VDE3845; NAMUR). The valve interface is equipped with an insert in the pinion bottom that allows both ISO5211 or DIN3337 mounting.
- The springs in the spring-return version allow a fail action in case of loss of air supply pressure (Fail-to-Close or Fail-to-Open).
- As from size AD0150 double-acting versions have flat end caps to reduce actuator length and internal air volume.

**IDENTIFICATION**  
FIGURE 1



| Size              | End Cap Design <sup>5</sup> |        | Spring Design <sup>6</sup>               |           |
|-------------------|-----------------------------|--------|--|-----------|
| 0012              | SR<br>                      | DA<br> | Left<br><br>Maximum 2 Loose Springs      | Right<br> |
| 0025<br>-<br>0100 | SR<br>                      | DA<br> | Left<br><br>Maximum 12 Spring Cartridges | Right<br> |
| 0150<br>-<br>0600 | SR<br>                      | DA<br> | Left<br><br>Maximum 12 Spring Cartridges | Right<br> |
| 0950<br>-<br>2500 | SR<br>                      | DA<br> | Left<br><br>Maximum 6 Loose Springs      | Right<br> |
| 4000              | SR<br>                      | DA<br> | Left<br><br>Maximum 6 Loose Springs      | Right<br> |

Notes

1. Top auxiliaries and Solenoid interface (VDI/VDE 3845; NAMUR) for size 0025 to 4000.
2. Valve interface available according ISO5211.
3. Spring-Return actuators: - with springs
4. Double-Acting actuators: - no springs
5. Actuator sizes 0025 to 0100 have high end caps for double-acting and spring-return models. Actuator sizes 0012 and 0150 to 4000 have low end caps for double-acting models and high end caps for spring-return models.
6. Actuator size 0012 is fitted with a maximum of 2 loose springs. Actuator sizes 0025 to 0600 are fitted with a maximum of 12 spring cartridges. Actuator sizes 0950 to 4000 are fitted with a maximum of 6 loose springs.

### 2.2 INTENDED USE

The Apollo Rack and Pinion actuators are intended for the automation and operation of quarter-turn valves like butterfly, ball and plug valves.

Rack and Pinion actuators can also be used to operate dampers or any other quarter-turn applications.

### 2.3 SPECIFICATIONS

#### PRESSURE RANGE

TABLE 1

| ACTUATOR TYPE | PRESSURE  |
|---------------|---|
| Double-Acting | 0.2 to 8.3 barg (2.9 to 120 psig)                         |
| Spring-Return | 6 to 8.3 barg (87 to 120 psig), with maximum spring set   |
|               | 3 to 8.3 barg (43.5 to 120 psig), reduced spring quantity |

#### OPERATING MEDIA

TABLE 2

| ACTUATOR TYPE                   | OPERATING MEDIA  |
|---------------------------------|--|
| Double-Acting and Single-Acting | Air, dry or lubricated and inert gases   |
|                                 | Dew point at least 10K below ambient temperature   |
|                                 | For sub-zero applications, take appropriate measures   |
|                                 | Mentioned pressure levels are "gauge pressures".<br>Gauge pressure is equal to absolute pressure minus atmospheric pressure. |

*Recommended air quality according ISO 8573-1 for normal operation: 7-5-4.*

#### NOTE

Use of filters, pressure regulators, lubricator and an oil/water separator mounted in the air supply line, will allow a smooth and durable operation of the actuator.

For lubricated supply air, it is recommended to use a non-detergent oil without aggressive additives, VG32, group 2 (ISO 3448).

#### TEMPERATURE RANGE

TABLE 3

| ACTUATOR TYPE            | TEMPERATURE                       |
|--------------------------|-----------------------------------|
| Standard                 | -20°C to +80°C (-4°F to +176°F)   |
| Option: Low Temperature  | -40°C to +80°C (-40°F to +176°F)  |
| Option: High Temperature | -10°C to +120°C (+14°F to +250°F) |

**AIR VOLUMES AND CONSUMPTION**  
TABLE 4

| ACTUATOR MODEL | ACTUATOR VOLUMES:            |                              |                               |
|----------------|------------------------------|------------------------------|-------------------------------|
|                | MAXIMUM VOLUME (IN LITERS)   |                              |                               |
|                | CENTRAL <sup>1</sup> CHAMBER | END CAP <sup>2</sup> CHAMBER | DISPLACED <sup>3</sup> VOLUME |
| 0012           | 0.05                         | 0.06                         | 0.04                          |
| 0025           | 0.14                         | 0.20                         | 0.08                          |
| 0040           | 0.26                         | 0.37                         | 0.15                          |
| 0065           | 0.40                         | 0.56                         | 0.22                          |
| 0100           | 0.6                          | 0.9                          | 0.3                           |
| 0150           | 1.0                          | 0.8                          | 0.5                           |
| 0200           | 1.3                          | 1.0                          | 0.7                           |
| 0350           | 2.1                          | 1.9                          | 1.2                           |
| 0600           | 3.6                          | 3.3                          | 2.1                           |
| 0950           | 4.9                          | 4.6                          | 3.2                           |
| 1600           | 7.9                          | 7.3                          | 5.4                           |
| 2500           | 12.6                         | 11.9                         | 8.3                           |
| 4000           | 21.7                         | 19.0                         | 13.5                          |


| CONSUMPTION PER STROKE (IN LITERS, PRESSURE IN BARG) |          |          |                    |          |          |
|--|----------|----------|--------------------|----------|----------|
| OUTWARD STROKE                                       |          |          | INWARD STROKE      |          |          |
| DOUBLE-ACTING AND SPRING-RETURN                      |          |          | DOUBLE-ACTING ONLY |          |          |
| 2.0 BARG   | 4.0 BARG | 8.0 BARG | 2.0 BARG           | 4.0 BARG | 8.0 BARG |
| 0.14   | 0.24     | 0.44     | 0.16               | 0.28     | 0.52     |
| 0.36   | 0.64     | 1.2      | 0.48               | 0.88     | 1.7      |
| 0.67   | 1.2      | 2.2      | 0.89               | 1.6      | 3.1      |
| 1.02   | 1.8      | 3.4      | 1.3                | 2.4      | 4.7      |
| 1.5  | 2.7      | 5.0      | 2.0                | 3.8      | 7.2      |
| 2.4  | 4.3      | 8.1      | 2.1                | 3.6      | 6.7      |
| 3.2  | 5.7      | 11       | 2.8                | 4.9      | 9.1      |
| 5.5  | 9.8      | 18       | 5.0                | 8.8      | 16       |
| 9.4  | 17       | 31       | 8.7                | 15       | 28       |
| 13   | 23       | 43       | 12                 | 22       | 40       |
| 21   | 37       | 69       | 20                 | 35       | 64       |
| 34   | 59       | 109      | 32                 | 56       | 104      |
| 57   | 100      | 187      | 52                 | 89       | 165      |

| ACTUATOR MODEL | ACTUATOR VOLUMES:            |                              |                               |
|----------------|------------------------------|------------------------------|-------------------------------|
|                | MAXIMUM VOLUME (CU.IN.)      |                              |                               |
|                | CENTRAL <sup>1</sup> CHAMBER | END CAP <sup>2</sup> CHAMBER | DISPLACED <sup>3</sup> VOLUME |
| 0012           | 3.1                          | 3.7                          | 2.5                           |
| 0025           | 8.5                          | 12.2                         | 4.7                           |
| 0040           | 15.9                         | 23                           | 8.9                           |
| 0065           | 24                           | 34                           | 13.5                          |
| 0100           | 36                           | 53                           | 19.9                          |
| 0150           | 58                           | 47                           | 32                            |
| 0200           | 76                           | 64                           | 44                            |
| 0350           | 131                          | 115                          | 76                            |
| 0600           | 222                          | 201                          | 129                           |
| 0950           | 301                          | 279                          | 196                           |
| 1600           | 484                          | 447                          | 328                           |
| 2500           | 769                          | 728                          | 508                           |
| 4000           | 1324                         | 1159                         | 825                           |

| CONSUMPTION PER STROKE (IN CU.IN., PRESSURE IN PSIG) |         |          |                    |         |          |
|--|---------|----------|--------------------|---------|----------|
| OUTWARD STROKE                                       |         |          | INWARD STROKE      |         |          |
| DOUBLE-ACTING AND SPRING-RETURN                      |         |          | DOUBLE-ACTING ONLY |         |          |
| 40 PSIG  | 80 PSIG | 120 PSIG | 40 PSIG            | 80 PSIG | 120 PSIG |
| 11   | 19      | 28       | 13                 | 23      | 33       |
| 28   | 52      | 75       | 38                 | 72      | 106      |
| 53   | 96      | 140      | 71                 | 133     | 196      |
| 81   | 148     | 215      | 107                | 200     | 294      |
| 118  | 216     | 314      | 165                | 310     | 455      |
| 192  | 352     | 512      | 163                | 293     | 424      |
| 255  | 466     | 676      | 220                | 397     | 573      |
| 436  | 796     | 1157     | 392                | 709     | 1025     |
| 742  | 1354    | 1967     | 683                | 1237    | 1790     |
| 1025   | 1854    | 2682     | 966                | 1735    | 2505     |
| 1662   | 2997    | 4331     | 1560               | 2792    | 4024     |
| 2630   | 4751    | 6873     | 2515               | 4523    | 6530     |
| 4477   | 8130    | 11782    | 4022               | 7219    | 10416    |

Notes  
 1. Pistons at 90° outward position.  
 2. Pistons at 0° inward position.  
 3. Stroke is 90°.

**ACTUATOR AIR VOLUMES**  
FIGURE 2



# AD/AD ACTUATOR IOM

## SECTION 3 - PART NUMBER MATRIX

### PART NUMBER MATRIX

| A      | S                 | 0100 | N  | 04         | A                   | C  | A        |
|--------|-------------------|------|--|------------|---------------------|--|----------|
| PREFIX | ACTION            | SIZE | SEAL OPTION  | SPRING SET | INSERTS             | FAIL POSITION  | REVISION |
| A      | D - DOUBLE ACTING | 0012 | N - NITRILE<br>NORMAL TEMP RANGE:<br>-4°F - 175°F    | 00 (DA)    | A - STANDARD SQUARE | C - FAIL CLOSED (FC)                                   | A        |
|        | S - SPRING RETURN | 0025 |  | 02         | B - WITHOUT INSERT  | F - FAIL OPEN (FO)                                     |          |
|        | K - KIT           | 0040 |  | 03         |                     | D - NO SPRING<br>(DOUBLE ACTING<br>FAIL LAST POSITION) |          |
|        |                   | 0065 | 04   |            |                     |  |          |
|        |                   | 0100 | H - FLUOROCARBON<br>HIGH TEMP RANGE:<br>-4°F - 250°F | 05         |                     |  |          |
|        |                   | 0150 |  | 06         |                     |  |          |
|        |                   | 0200 | L - SILICONE<br>LOW TEMP RANGE:<br>-40°F - 175°F     |            |                     |  |          |
|        |                   | 0350 |  |            |                     |  |          |
|        |                   | 0600 |  |            |                     |  |          |
|        |                   | 0950 |  |            |                     |  |          |
|        |                   | 1600 |  |            |                     |  |          |
|        |                   | 2500 |  |            |                     |  |          |
|        |                   | 4000 |  |            |                     |  |          |

**EXAMPLE: AS0100N04ACA = Spring Return, 0100 Size, Nitrile Seals, 04 Spring Set, Standard Square Drive, Fail Closed**

This section explains:

- The actuator rotation direction.
- In which position the actuator will end after a failure.
- Principles of operation:
  - Solenoid operation.
  - Double acting and spring return operation.
- Assembly codes.
- Actuator to valve assembly.

### 4.1 BEFORE YOU START

**⚠ CAUTION ⚠**

In case of an air or electrical failure, it is important to know the behavior of the actuator. Before mounting the actuator on a valve, consult the following sections below.


### 4.2 ACTUATOR ROTATION DIRECTION

#### 4.2.1 VALVE ROTATION

For the following paragraphs we assume that valves rotate as indicated in Figure 3.

#### NORMAL VALVE ROTATION

FIGURE 3



#### 4.2.2 POSITION AFTER FAILURE

The position of the actuator after a failure depends on the:

1. Principle of operation.
2. Assembly code.
3. Kind of failure. Refer to the table below.

#### POSITION AFTER FAILURE

TABLE 5

| PRINCIPLE OF OPERATION                 | ASSEMBLY CODE | KIND OF FAILURE | POSITION    |
|--|---------------|-----------------|-------------|
| Double-Acting Actuator                 | CW            | Pressure        | Not defined |
|  |               | Signal          | Closed      |
|  |               | Supply Voltage  | Closed      |
|  | CC            | Pressure        | Not defined |
|  |               | Signal          | Open        |
|  |               | Supply Voltage  | Open        |
| Single-Acting (Spring-Return) Actuator | CW            | Pressure        | Closed      |
|  |               | Signal          | Closed      |
|  |               | Supply Voltage  | Closed      |
|  | CC            | Pressure        | Open        |
|  |               | Signal          | Open        |
|  |               | Supply Voltage  | Open        |


### 4.3 PRINCIPLES OF OPERATION

#### 4.3.1 SOLENOID VALVE

All actuators can be either piped with solid or flexible tubing with the solenoid valve mounted remotely from the actuator or by mounting a VDI/VDE 3845 (NAMUR) designed solenoid valve DIRECTLY onto the NAMUR mounting pad on the side of the actuator.

#### TYPICAL SOLENOID OPERATION

FIGURE 4



#### OPERATING SPEED

TABLE 6

| ACTUATOR SIZE | CYCLE TIME IN SECONDS |               |                    |                    |
|---------------|-----------------------|---------------|--------------------|--------------------|
|               | SPRING-RETURN         |               | DOUBLE-ACTING      |                    |
|               | A-PORT PRESSURIZED    | SPRING STROKE | A-PORT PRESSURIZED | B-PORT PRESSURIZED |
| 0012          | 0.4                   | 0.4           | 0.4                | 0.4                |
| 0025          | 0.5                   | 0.4           | 0.5                | 0.4                |
| 0040          | 0.6                   | 0.5           | 0.6                | 0.5                |
| 0065          | 0.7                   | 0.5           | 0.6                | 0.6                |
| 0100          | 0.8                   | 0.6           | 0.8                | 0.7                |
| 0150          | 1.0                   | 0.8           | 0.9                | 0.8                |
| 0200          | 1.3                   | 0.9           | 1.0                | 1.0                |
| 0350          | 1.9                   | 1.3           | 1.4                | 1.5                |
| 0600          | 3.2                   | 1.9           | 2.2                | 2.2                |
| 0950          | 6.6                   | 2.2           | 2.4                | 2.0                |
| 1600          | 10.6                  | 3.5           | 3.6                | 3.3                |
| 2500          | 16.9                  | 5.7           | 5.8                | 5.2                |
| 4000          | 29.1                  | 9.2           | 9.2                | 9.0                |

Operating time is average with actuator under load and solenoid valve fitted.

Test conditions:  
 1. Solenoid with flow capacity: 0.6 m<sup>3</sup>/hr  
 2. Pipe diameter: 6mm  
 3. Medium: clean air  
 4. Supply pressure: 5.5 bar (80psi)  
 5. Load: with average load  
 6. Stroke: 90°  
 7. Temperature: room temperature

#### 4.3.2 INGRESS PROTECTION (IP) RATING

Apollo actuators are IP66/IP67 rated. In case of IP66 or IP67 requirements, take precautions that comply with the IP66/IP67 requirements to prevent moisture or dust from entering the actuator through the open air exhaust port(s), either directly on the actuator or at the exhaust ports of the connected solenoid valve.

We recommend to connect tubing to the exhaust(s) and lead this into a dry and dust free area, or to use check valves in the exhaust.

### 4.3.3 DOUBLE-ACTING ACTUATORS



The operating principle, as explained here, is applicable for actuators with assembly code CW (direct acting).

- Applying supply pressure to port A will move the pistons outward to the “Open” position of the valve.
- Applying supply pressure to port B will move the pistons inward to the “Close” position of the valve.
- For assembly codes CC, the operating principle is reversed (reverse acting).



#### DOUBLE-ACTING OPERATION

FIGURE 5

Outward Stroke



Inward Stroke



### 4.3.4 SPRING-RETURN ACTUATORS



The operating principle, as explained here, is applicable for actuators with assembly code CW (direct acting).

- Applying supply pressure to port A will move the pistons outwards to the “Open” position of the valve.
- Venting the supply pressure from port A will cause the springs to move the pistons inwards to the “Close” position of the valve.
- For assembly codes CC, the operating principle is reversed (reverse acting).



#### SPRING-RETURN OPERATION

FIGURE 6

Outward Stroke




Inward Stroke



### 4.4 ACTUATOR ASSEMBLY CODE


#### ASSEMBLY CODE - DOUBLE-ACTING

FIGURE 7



#### ASSEMBLY CODE - SPRING-RETURN

FIGURE 8



A = Rotation when central air chamber is pressurized.  
 B = Rotation when end cap air chambers are pressurized.

All views are from above. Pistons are shown in inward position.

### 4.5 ACTUATOR TO VALVE INSTALLATION

**⚠ CAUTION ⚠**

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Stay away from moving parts to prevent serious injuries. When test cycling the actuator and valve assembly by applying pressure to the A or B port, be aware that there are moving parts like pinion top, actuator to valve coupling and the valve- blade, ball, plug, etc.




**NOTICE**

The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers. For the removal of inserts, a special extractor tool can be supplied on request.

During assembly to the valve, do not hit with hammer on pinion top. This can damage the pinion top washer and cause premature failure. Before mounting the actuator on the valve or valve bracket, be sure that both the actuator and the valve are in the same closed or open position.


Refer to appendix B, Tool and Torque tables, for using the right size tool.

**TOOLS**  
TABLE 7

| SYMBOL  | TOOL  |
|---|---|
|    | Wrench - All Types & Sizes. Metric and Imperial |
|  | Circclip Pliers                                 |
|  | Allen Key                                       |

1. Remove handle nut, handle, lock washer, and etc. from the valve if required.
2. Visually check to make sure the valve is CLOSED.

**VALVE HANDLE REMOVAL**  
FIGURE 9




- When required, check if the insert drive (23) is mounted. If not, use a plastic mallet and tap slightly until the reducer square is in the required position.

Be sure that the insert is mounted at 90° or 45°. It is possible to mount the insert turned 22.5°. This way the valve will not open or close the right way.

### INSERT DRIVE INSTALLATION


FIGURE 10



- Install the bracket to the valve flange. Tighten all bolts and nuts and apply the correct torque.

### BRACKET INSTALLATION

FIGURE 11



- Install the actuator to the bracket. Tighten all bolts and apply the correct torque (refer to Table 8).

**BOTTOM FLANGE TORQUE VALUES**  
TABLE 8


| ACTUATOR SIZE    | ISO PATTERN        | TORQUE (LB.FT) |       |       |
|------------------|--------------------|----------------|-------|-------|
|                  |                    | THREAD         | MIN.  | MAX.  |
| 0012             | F04                | 10-24UNC       | 3.3   | 3.7   |
| 0025             | F03 inner pattern  | 10-24UNC       | 1.5   | 2.2   |
|                  | F05 outer pattern  | 1/4"-20        | 3.3   | 3.7   |
| 0040, 0065, 0100 | F05 inner pattern  | 1/4"-20        | 3.3   | 3.7   |
|                  | F07 outer pattern  | 5/16"-18       | 7.7   | 9.2   |
| 0150, 0200, 0350 | F07 inner pattern  | 5/16"-18       | 7.7   | 9.2   |
|                  | F10 outer pattern  | 3/8"-16        | 15.5  | 18.1  |
| 0600             | F10 inner pattern  | 3/8"-16        | 15.5  | 18.1  |
|                  | F12 outer pattern  | 1/2"-13        | 25.4  | 31.7  |
| 0950             | F10 inner pattern  | 3/8"-16        | 15.5  | 18.1  |
|                  | F14 outer pattern  | 5/8"-11        | 66.4  | 76.7  |
| 1600, 2500       | F16 inner pattern  | 3/4"-10        | 125.4 | 150.5 |
|                  | F25* outer pattern | 4x 5/8"-11     | 66.4  | 76.7  |
| 4000             | F16 inner pattern  | 3/4"-10        | 125.4 | 150.5 |
|                  | F25 outer pattern  | 8x 5/8"-11     | 66.4  | 76.7  |

- When required, mount or adjust the visual indicator (26).


### INDICATOR MOUNTING

FIGURE 12

#### INDICATOR MOUNTING "IN-LINE"



#### INDICATOR MOUNTING "ACROSS-LINE"



### 4.6 MOUNTING OF CONTROL AND FEEDBACK ACCESSORIES

Solenoid valve and or switch boxes can now be mounted to the actuator. Check the instructions as shipped with these components for installation, operating and maintenance instructions.

We recommend to test-cycle the complete assembly to check correct operation.

### 4.7 RECOMMENDED TUBING SIZES

In case the solenoid valve is mounted remotely (i.e. in a central solenoid cabinet) and in order to supply sufficient flow of air supply to the actuator, the following tubing sizes are recommended.

#### TUBING SIZES

TABLE 9

| ACTUATOR SIZE                | RUNS UP TO |          | RUNS OVER TO |           |
|------------------------------|------------|----------|--------------|-----------|
|                              | 1.2 METERS | 4 FEET   | 1.2 METERS   | 4 FEET    |
| 0025, 0040, 0065             | 6 mm       | 1/4 inch | 6 mm         | 1/4 inch  |
| 0100, 0150, 0200, 0350, 0600 | 6 mm       | 1/4 inch | 8 mm         | 5/16 inch |
| 0950, 1600, 2500, 4000       | 6 mm       | 1/4 inch | 10 mm        | 3/8 inch  |

# AD/AD ACTUATOR IOM

## SECTION 5 - MECHANICAL STROKE ADJUSTMENTS

This section explains:

- What mechanical stroke adjustment is.
- What the factory settings are.
- How to adjust the travel stops.

Apollo actuator sizes 0025 to 4000 have two stroke adjustment stops for adjusting accurately the stroke of the actuator/valve assembly in open and closed position.


The smallest actuator, size 0012, does not have limit stops.

The factory setting of the stroke is 90°. Most quarter-turn valve applications will not require readjustment of these settings.

If required the stroke can be adjusted by means of two-stroke adjustment bolts.

### FACTORY SETTING

FIGURE 13



### 5.1 TRAVEL STOP ADJUSTMENT

**▲ CAUTION - PRESSURIZED ACTUATOR ▲**

Do not turn out the travel stops completely when the actuator is pressurized.


When adjusting the travel stops and the actuator is still pressurized, the travel stops can be “shot” away when completely turned out.

#### 5.1.1 DOUBLE-ACTING ACTUATORS

1. Operate valve/actuator assembly to the required “Closed” position.
2. Remove air supply.
3. Slacken locknut on the “closed” stop (2).

#### DOUBLE-ACTING ACTUATORS TRAVEL STOPS

FIGURE 14




4. Turn the “closed” stop clockwise to reduce or counterclockwise to increase the travel. Consult chapter 5.1.3 (angular displacement of the pinion), to define how far the limit stop must be turned in or out.
5. Tighten the lock nut.
6. Connect air and cycle the actuator to check that the position is correct. If not repeat from 2.
7. Remove air supply.
8. For adjusting the open position repeat steps 1 to 7, but now for the open position and “open” stop (1).

#### 5.1.2 SPRING-RETURN ACTUATORS

1. Connect air supply to the A port. Actuator will move to the open position.
2. Slacken locknut (24) on the “closed” stop (2).

#### SPRING-RETURN ACTUATORS TRAVEL STOPS

FIGURE 15



3. Turn the “closed” stop clockwise to reduce or counterclockwise to increase the travel. Consult chapter 5.1.3 (angular displacement of the pinion), to define how far the limit stop must be turned in or out.
4. Remove air supply. Actuator will move to the closed position.
5. Check whether the actuator valve assembly is in the required position. If not repeat steps 1 to 5.
6. Remove air supply.
7. For adjusting the open position repeat steps 1 to 6, but now for the open position and “open” stop (1).

### LIMIT STOP DIMENSIONS

TABLE 10

| ACTUATOR SIZE | THREAD | BOLT WRENCH            | NUT WRENCH             |
|---------------|--------|------------------------|------------------------|
|               |        | SIZE (MM)              | SIZE (MM)              |
| 0025          | M 6    | 10                     | 10                     |
| 0040          | M 8    | 13                     | 13                     |
| 0065          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0100          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0150          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0200          | M 12   | 19 (18) <sup>1,2</sup> | 19 (18) <sup>1,2</sup> |
| 0350          | M 16   | 24                     | 24                     |
| 0600          | M 20   | 30                     | 30                     |
| 0950          | M 22   | 12                     | 32                     |
| 1600          | M 24   | 14                     | 36                     |
| 2500          | M 27   | 17                     | 41                     |
| 4000          | M 22   | 12                     | 32                     |

1. Default dimension according DIN933 standard.
2. Dimensions in brackets according ISO4017 standard.
3. Actuator size 0012 is not available with limit stops.

### 5.1.3 ANGULAR DISPLACEMENT

Below table identifies, per actuator size, what the angular displacement of the pinions is, when using the limit stop screws.

- Turn the limit stop clockwise reduces the stroke.
- Turn the limit stop counterclockwise to increase the stroke.

### ANGULAR DISPLACEMENT LIMIT STOP

TABLE 11

| ACTUATOR SIZE | TURNS FOR 5° ADJUSTMENT OF THE PINION                | 360° REVOLUTION OF LIMIT STOP SCREW WILL ADJUST |
|---------------|--|---|
| 0012          | Actuator size 0012 is not available with limit stops |   |
| 0025          | 0.7  | 7.1°  |
| 0040          | 0.8  | 6.3°  |
| 0065          | 0.6  | 8.3°  |
| 0100          | 0.7  | 7.1°  |
| 0150          | 1.2  | 4.2°  |
| 0200          | 1.0  | 5.0°  |
| 0350          | 0.8  | 6.3°  |
| 0600          | 0.8  | 6.3°  |
| 0950          | 1.1  | 4.7°  |
| 1600          | 1.3  | 4.1°  |
| 2500          | 1.5  | 3.4°  |
| 4000          | 3.2  | 1.6°  |

### NOTICE

In case of air leakage over the limit stop bolts, turn the lock nut of the limit stop bolts tighter, until leakage stops.

This section explains:

- When and how to do maintenance.
  - Normal maintenance.
  - Extraordinary maintenance.
- What to do when replacing springs.
- What the availability is of spare parts, action conversion kits and temperature conversion kits.

### ▲ CAUTION ▲

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembling the actuator, consult the relevant sections of this manual.

## 6.1 NORMAL MAINTENANCE

Apollo actuators are designed to operate without maintenance for their normal working life. Normal working life is 500,000 cycles\* for sizes up to 01600 and 250,000 for sizes 2500 and 4000.

For actuators with the optional low temperature silicon seals, we advise to replace these seals after 250,000 cycles\*.

\*Cycles = one open stroke and one close stroke.

We recommend regular inspections to make certain that the actuator/valve assembly operates smoothly and to check that there are no visible or audible defects. We advise to perform the following checks upon each proof test interval complying with the rules and regulations of the country of final installation:

- Visually check the entire actuator as well as the control system (where foreseen).
- Ensure there are no leaks on the actuator parts under pressure.
- Check pneumatic connections for leaks. Tighten tube fittings as required.
- Check if manual override (where foreseen) is regular.
- Check if pneumatic filter cartridge (where foreseen) is sound and filter bowl (where foreseen) has been cleaned properly.
- Check the setting of the relief valves (where foreseen).
- Verify that the power fluid supply pressure value is within the required range.
- Remove built-up dust and dirt from all actuator surfaces.
- Inspect actuator paint work for damages to ensure continued corrosion protection. Touch-up as required in accordance with the applicable paint specification.
- Operate the actuator/valve assembly for 2 complete open/close cycles with complete closing of the valve.
- Verify the correct performing of open – close operations (e.g. check locally, or automatically via Logic solver, the correct movement of the actuator).

All actuators are supplied with sufficient lubrication for their normal working life. If required, see Section 9.1 (Grease instructions) for the recommended grease.

For mounting the parts of the repair kit follow the instruction of the Decommission, Disassembly and Reassembly chapters of this manual.

## 6.2 INSPECTION AND REPAIR

Replacement of internal seals and bearings allows you to extend the normal working life. Service kits, containing all necessary spare parts (like seals, bearings, grease and instructions) can be obtained.

### 6.2.1 SERVICE KITS

All soft seals, bearings, and nonreusable parts are included in the recommended service kit. The service kit is identical for both the double-acting and the spring-return models.

### 6.2.2 SPRING-RETURN ACTUATOR

For the spring-return models, we recommend a set of spare springs for each different model in addition to the recommended spare parts kit.

On spring-return actuators, the spring cartridges can be replaced. **SPRING CARTRIDGES SHOULD ALWAYS BE REPLACED IN COMPLETE SETS.**

This section explains:

- How to decommission an actuator in a safe way.

### 7.1 BEFORE YOU START

#### ⚠ CAUTION - MOVING PARTS ⚠

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembling the actuator consult the relevant sections of this manual.

Actuator can move when removing supply pressure and/or electrical control signal of actuators. If not already there, a spring-return actuator will cycle to its fail position.

When removing any ball valve or plug valve assemblies from a pipe system, isolate the piping system on which the Actuator is installed and relieve any media pressure that may be trapped in the valve cavities before removing the actuator for maintenance.

A spring-return actuator mounted on a valve, which is stuck in mid stroke, contains a high spring load which will cause a sudden rotation of the actuator versus the valve or valve bracket during disassembly. This can cause serious injury to personnel or damage to property.

Refer to Appendix A for instructions to safely remove the spring load before disassembling the spring-return actuator from valve or bracket.


### 7.2 REMOVING THE ACTUATOR FROM THE VALVE

1. Disconnect all air supply hoses (Ports A and B or solenoid).
2. Disconnect all electrical wirings of the switch box.
3. Disconnect the electrical wiring of the solenoid valve.
4. Remove the bolts and nuts from the valve flange.
5. Remove the bracket from the actuator.
6. Remove the switch box and solenoid valve.

Refer to the documentation of the switch box and solenoid valve for safe disassembly.

#### REMOVING ACTUATOR FROM VALVE

FIGURE 16



# AD/AD ACTUATOR IOM

## SECTION 8 - DISASSEMBLY

This section explains:

- How to disassemble an actuator safely.

The instructions of this section can be used for maintenance or reconfiguration like spring set change or maintenance.

Reference numbers for components refer to the exploded view in section 11.

In case of maintenance, discard all the used soft parts like O-ring seals, guide bands, wear strips, and circlip.

### **▲ CAUTION ▲**

Actuator must be isolated pneumatically and electrically before any (dis)assembly starts. Before mounting or (dis)assembling the actuator, consult the relevant sections of this manual.

### **▲ CAUTION - SPRING FORCE ▲**

Spring-return actuators contain springs in a compressed state. Follow these instructions to release the spring force safely.

The end caps of spring-return actuators sizes 0025 to 0600 should be free of the spring load after 10 full turns (crosswise relaxing) of the end cap screws. If there is still spring load on the end cap, this might indicate a broken spring cartridge. Stop this disassembly procedure immediately. Continuing might cause the end cap to be “shot” away causing serious injury.

Spring return actuator size 0950 to 4000 have long end cap screws to release the spring load safely.

Refer to Appendix A for instructions to safely remove the spring load before disassembling the end cap of a spring-return actuator with a broken spring cartridge.

### **NOTICE**

The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers.

Refer to the tables in this section or refer to appendix B Tool and Torque tables.


### 8.1 REMOVING END CAPS (SIZES 0025 TO 0600)

#### DOUBLE-ACTING ACTUATORS

1. Remove the screws (8) and washers (10) of the end caps (6).
2. Remove the o-ring (11) and “B” port seal (2). Discard these parts.

#### END CAPS REMOVAL - DOUBLE-ACTING (SIZES 0025 TO 0600)

FIGURE 17



Double acting end caps (6) are fitted with a white warning sticker.

Spring return end caps (5) are fitted with a black warning sticker.

Actuator sizes 0025 to 0100 have high end caps for double-acting and spring-return models.


Actuator sizes 0150 to 4000 have low end caps for double-acting models and high end caps for spring return models.

### SPRING-RETURN ACTUATORS

1. Tip: For actuators with assembly code CW, turn back the right hand limit stop screw (30) 2 full turns.  
For actuators with assembly code CC, turn back the left hand limit stop screw (30) 2 full turns.  
This will lower the spring force on the end cap and reduces the screw out length of the end cap screws.
2. Uniformly loosen the screws (9) of the end caps (5) 1/4 - 1/2 turns at a time, in sequence, as per figure 18, to relieve the pre-load of the springs.
3. Remove the o-rings (11) and "B" port seals (2). Discard these parts.

### END CAPS REMOVAL - SPRING-RETURN (SIZES 0025 TO 0600)

FIGURE 18




### 8.2 REMOVING END CAPS (SIZES 0950 TO 4000)

#### DOUBLE-ACTING ACTUATORS

1. Remove the screws (8) and washers (10) of the end caps (6).
2. Remove the o-ring (11) and "B" port seal (2). Discard these parts.

#### END CAPS REMOVAL - DOUBLE-ACTING (SIZES 0950 TO 4000)

FIGURE 19




#### SPRING-RETURN ACTUATORS

1. Tip: For actuators with assembly code CW, turn back the right hand limit stop screw (30) 2 full turns.  
For actuators with assembly code CC, turn back the left hand limit stop screw (30) 2 full turns.  
This will lower the spring force on the end cap and reduces the screw out length of the end cap screws.
2. Uniformly loosen the screws (9) of the end caps (5) 1/4 - 1/2 turns at a time, in sequence, as per figure 20, to relieve the pre-load of the springs.
3. Remove the o-rings (11) and "B" port seals (2). Discard these parts.

#### END CAPS REMOVAL - SPRING-RETURN (SIZES 0950 TO 4000)

FIGURE 20




### 8.3 REMOVING SPRING CARTRIDGES OR SPRINGS

1. Remove the spring cartridges or springs (7).


#### SPRING CARTRIDGES REMOVAL - SIZES 0025 TO 0600

FIGURE 21



#### SPRING CARTRIDGES REMOVAL - SIZES 0950 TO 4000

FIGURE 22




### 8.4 REMOVING LIMIT STOP SCREWS

1. Remove the limit stop screws (30), limit stop nuts (31), limit stop washers (32) and limit stop o-rings (33). Discard the o-rings.

#### LIMIT STOP SPRINGS REMOVAL

FIGURE 23




### 8.5 REMOVING PISTONS

1. Use a wrench and turn the pinion counterclockwise until the pistons (14) come out of the body.
2. Remove the piston bearings (15), piston rack bearing strips (17) and piston o-ring seals (16). Discard these parts.

#### PISTON REMOVAL

FIGURE 24




### 8.6 REMOVING PINION

1. Remove the circlip (27) and thrust bearing (23) on top of the pinion assembly.  
For sizes 0950 to 4000 remove also the top pinion bearing (19).
2. Remove the pinion (18) by pushing it downwards.  
For Size 4000, remove the backup ring (29), O-ring pinion top (21) the cam (24) and cam thrust washer (25) through the main bore of the housing.
3. Remove the pinion O-ring seals (21/22) and the pinion bearings (19/20).  
For Size 0950 to 2500, remove also the backup ring (29).
4. Discard all of these parts.

### PINION REMOVAL

FIGURE 25



### RECOMMENDED CIRCLIP PLIERS ACCORDING DIN 5254 (OR EQUAL) FOR SHAFT CIRCLIPS

TABLE 12

| ACTUATOR SIZE | PINION TOP DIAMETER | PLIERS ACCORDING DIN 5254 | ACTUATOR SIZE | PINION TOP DIAMETER | PLIERS ACCORDING DIN 5254 |
|---------------|---------------------|---------------------------|---------------|---------------------|---------------------------|
| 0012          | 16 mm               | 0.630"                    | 0950          | 65 mm               | 2.559                     |
| 0025 - 0100   | 22 mm               | 0.866"                    | 1600          | 75 mm               | 2.953                     |
| 00150 - 0350  | 36 mm               | 1.417"                    | 2500          | 95 mm               | 3.74                      |
| 0600          | 55 mm               | 2.165"                    | 4000          | 96 mm               | 3.78                      |

### 8.7 CLEANING THE COMPONENTS

In case of maintenance, use a clean dry cloth and thoroughly wipe clean and remove old grease from:

- The inside and outside of the body including thread holes and crevices/grooves
- The pinion gears
- The pistons

This section explains:

- Which parts and how to grease them.
- How to reassemble a complete actuator.
- How to set the stroke adjustment bolts after reassembly.
- How to do a basic function and air leak test.

The instructions of this section can be used for maintenance or reconfiguration like spring set change or maintenance. Reference numbers for components refer to the exploded view in section 11.

In case of maintenance, discard all used soft parts like O-ring seals, guide bands and wear strips and circlip and replace them with the parts as supplied in the repair kit.

In case of reconfiguration replace the parts as supplied in the conversion kit (see also chapter 6).

### **NOTICE**

The actuator is designed to be installed, commissioned and maintained using generic tools like wrenches, Allen keys and screwdrivers.

Refer to the tables in this section or refer to Appendix B Tool and Torque tables.

### 9.1 GREASE INSTRUCTIONS

Check the product coding on the product labels and chapter 3 of this manual, to define which type of grease to use.

- For standard actuators (-20°C to +80°C / -4°F to +176°F):  
Castrol High Temperature grease (or equivalent).
- For low temperature operation (-40°C to +80°C / -40°F to +176°F):  
Castrol Tribol GR TT 1 PD (previously known as Castrol OPTITEMP TT1) or LG2 grease (or equivalent).
- For high temperature operation (-10°C to +120°C / +14°F to +250°F):  
Castrol High Temperature grease (or equivalent).

We recommend using a suitable sized paint brush to apply the required amount of grease on the parts as per Table 12 and Figure 23.


### GREASE INSTRUCTIONS

TABLE 13

| PART           | SECTION OF PART | AMOUNT OF GREASE              |
|----------------|-----------------|-------------------------------|
| O-rings:       | A               | Completely                    |
|                | B               | Piston bore                   |
| Housing Parts: | C               | Top pinion bore               |
|                | D               | Bottom pinion bore            |
|                | E               | O-ring & bearing groove       |
| Piston Parts:  | F               | Rack teeth                    |
|                | G               | Piston bearing                |
|                | H               | Piston rack bearing strip     |
|                | J               | Pinion bottom & O-ring groove |
| Piston Parts:  | K               | Pinion top & O-ring groove    |
|                | L               | Gear teeth                    |
|                | M               | Pinion top bearing            |
|                | N               | Pinion bottom bearing         |
|                |                 |                               |

### GREASE INSTRUCTIONS

FIGURE 26




### 9.2 REASSEMBLY OF THE PINION

- Grease the pinion parts according to chapter 9.1.
  - Install the pinion bearings (19/20) and the O-ring seals (21/22) on the pinion (18)  
For Size 0950 to 2500, install also the the backup ring (29).
  - Insert the pinion (18) in the housing. For size 4000: mount first the cam (24), cam thrust washer (25), pinion top O-ring (21) and backup ring (29) through the mainbore onto the pinion (18).
  - For sizes 0950 to 4000 install first the top pinion bearing (19).  
For all sizes, install the thrust washer (23) and mount the circlip (27) on the pinion top.
- Install the new circlip onto its mating groove on the top shaft extension and with the non-sharp edge (2) towards the housing and the sharp edge (1) towards the top of the shaft.

### REASSEMBLE THE PINION

FIGURE 27



**RECOMMENDED CIRCLIP PLIERS ACCORDING DIN 5254 (OR EQUAL) FOR SHAFT CIRCLIPS**  
TABLE 14

| ACTUATOR SIZE | PINION TOP DIAMETER |        | PLIERS ACCORDING DIN 5254 |
|---------------|---------------------|--------|---------------------------|
| 0012          | 16 mm               | 0.630" | A1                        |
| 0025 - 0100   | 22 mm               | 0.866" | A2                        |
| 00150 - 0350  | 36 mm               | 1.417" | A3                        |
| 0600          | 55 mm               | 2.165" | A3                        |

| ACTUATOR SIZE | PINION TOP DIAMETER |       | PLIERS ACCORDING DIN 5254 |
|---------------|---------------------|-------|---------------------------|
| 0950          | 65 mm               | 2.559 | A3                        |
| 1600          | 75 mm               | 2.953 | A3                        |
| 2500          | 95 mm               | 3.74  | A4                        |
| 4000          | 96 mm               | 3.78  | A4                        |

### 9.3 REASSEMBLY OF THE PISTONS


- Grease the piston parts according to step 9.1.
- Install the piston rack bearing strips (17) and piston O-ring seals (16) on the pistons (14). Ensure all these parts are kept in place during assembly.

**NOTICE**

Before reassembling the pistons, check the required assembly code (see section 4.2).

### REASSEMBLE THE PISTONS

FIGURE 28




- Align the pinion (see Figure 28) so that the teeth on the pinion will pick up the pistons rack teeth when turning the pinion. The position of the pinion top slot and the cam on the pinion top:
  - For standard or Spring-to-Close: Assembly Code CW.
  - For reverse or Spring-to-Open: Assembly Code CC.
- Slightly push the pinion inward to engage with the pinion.
  - Ensure that smooth movement and 90-degree operation can occur without moving the pistons out of the actuator body.
  - For larger pistons, use a rubber mallet and slightly hitting the pistons inward to engage with the pinion.
- When the pistons are moved 90° inwards, check that the pinion slot on the pinion top is:
  - Perpendicular to the length centre line of the house for assembly code CW.
  - In line to the length centre line of the house for assembly code CC.
- If not, turn pinion to move the pistons outward until they disengage from the pinion. Shift one tooth of the pinion, reassemble and check again.
- Move the pistons outward so that just the bearing groove sticks out of the housing. Fold the piston bearings (15) around the piston and hold the bearing ends in place while moving the pistons inwards.
  - For larger pistons, use a rubber mallet and slightly hitting the pistons inward to engage with the pinion.

### POSITION OF THE SLOT AND THE CAM ON THE PINION TOP

FIGURE 29


ASSEMBLY CODE: CW

Standard, spring-to-close



ASSEMBLY CODE: CC

Reverse, spring-to-open



**NOTICE**

When the pistons are completely moved inwards, the pinion top will show a 5° over travel.


- A = Position of cam
- B = Position of slot and dot in pinion
- C = Final position of pinion dot

### 9.4 REASSEMBLY AND SETTING OF THE LIMIT STOPS

1. Install the limit stop screws (30), limit stop nuts (31), limit stop washers (32) and limit stop O-rings (33).

#### INSTALL LIMIT STOP BOLTS

FIGURE 30



2. Move the pistons inward until the slot in the top of the pinion is perpendicular to centerline of the housing.
3. Double check if the position of the slot and the cam on the pinion top is in the correct position (see figure 30). Screw in the right hand travel stop until it comes into contact with the pinion stop face.
4. Move the pistons outward until the slot in the top of the pinion is in line with the centerline of the housing.
5. Screw in the left hand travel stop until it comes into contact with the pinion stop face.
  - For accurate travel stop adjustment of the actuator on the valve, see section 5.


### 9.5 REASSEMBLY OF THE END CAPS

#### 9.5.1 DOUBLE-ACTING ACTUATORS

- Grease the O-ring seals (11) and B port seals (2) according to step 9.1.
- Ensure that O-ring seals (11) and B port seals (2) are kept in place during assembly.
- Install the end caps (6) and tighten the end cap screws (8). Refer to Table 15 for the correct torque.

#### END CAPS REASSEMBLY - DOUBLE-ACTING

FIGURE 31



Double acting end caps (6) are fitted with a white warning sticker.

Spring return end caps (5) are fitted with a black warning sticker.

Actuator sizes 0025 to 0100 have high end caps for double-acting and spring-return models.

Actuator sizes 0150 to 4000 have low end caps for double-acting models and high end caps for spring return models.

#### END CAP SCREW TORQUE

TABLE 14

| ACTUATOR SIZE | THREAD | TOOL      | SIZE | TORQUE (NM) |      |      | TORQUE (LB.FT) |      |      |
|---------------|--------|-----------|------|-------------|------|------|----------------|------|------|
|               |        |           |      | TARGET      | MIN. | MAX. | TARGET         | MIN. | MAX. |
| 0012          | M4     | Allen key | SW 3 | 1.1         | 0.8  | 1.3  | 0.8            | 0.6  | 1.0  |
| 0025          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0040          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0065          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0100          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0150          | M6     |           | SW 5 | 3.3         | 2.6  | 5.1  | 2.4            | 1.9  | 3.8  |
| 0200          | M6     |           | SW 5 | 3.3         | 2.6  | 5.1  | 2.4            | 1.9  | 3.8  |
| 0350          | M8     |           | SW 6 | 8.4         | 6.7  | 12.2 | 6.2            | 4.9  | 9.0  |
| 0600          | M10    |           | SW 8 | 15.3        | 12.2 | 24.8 | 11.3           | 9.0  | 18.3 |
| 0950          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 1600          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 2500          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 4000          | M14    |           | SW12 | 43.5        | 34.8 | 66.4 | 32.1           | 25.7 | 49.0 |

### 9.5.2 SPRING-RETURN ACTUATORS (SIZES 0025 TO 0600)

#### NOTICE

Apollo spring return actuators are supplied with springs on each side of the actuator. Throughout the size range, there are three different spring designs:

Size 0012 has only 1 spring on each side.

Sizes 0025 to 0600 have 6 springs on each side (see figure 32).

Sizes 0950 to 4000 have 3 springs on each side (see chapter 9.5.3).


Check below figures to see where to place the spring cartridges in case of spring set conversion.

When replacing spring cartridges in a spring-return actuator, ensure that the cartridges are replaced in their identical position from where they were removed.

Before assembling the spring cartridges and end caps, make sure that the pistons are completely inwards.

#### SPRING PLACEMENT (SIZES 0025 TO 0600)

FIGURE 32




A = Piston top view  
B = Position of gear rack

1. Grease the O-ring seals (11) and B port seals (2) according to step 9.1.
2. Ensure that O-ring seals (11) and B port seals (2) are kept in place during assembly.
3. Place the spring cartridges in actuator as per required spring set (see Figure 32).
4. Put the end cap screw washer (10) on the end cap screw (9) and tighten each end cap screw in small equal turns and in the sequence as per Figure 33. Refer to Table 15 for the correct torque. We recommend to use some grease on the screws for easier fastening.

### END CAPS REASSEMBLY - SPRING-RETURN (SIZES 0025 TO 0600)

FIGURE 33



### 9.5.3 SPRING-RETURN ACTUATORS (SIZES 0950 TO 4000)

#### NOTICE

Apollo spring return actuators are supplied with springs on each side of the actuator. Throughout the size range, there are three different spring designs:

Size 0012 has only 1 spring on each side.

Sizes 0025 to 0600 have 6 springs on each side (see chapter 9.5.2).

Sizes 0950 to 4000 have 3 springs on each side (see figure 34).


Check below figures to see where to place the spring cartridges in case of spring set conversion.

When replacing spring cartridges in a spring-return actuator, ensure that the cartridges are replaced in their identical position from where they were removed.

Before assembling the spring cartridges and end caps, make sure that the pistons are completely inwards.

#### SPRING PLACEMENT (SIZES 0950 TO 4000)

FIGURE 34



A = Piston top view


B = Position of gear rack

1. Grease the O-ring seals (11) and B port seals (2) according to step 9.1.
2. Ensure that O-ring seals (11) and B port seals (2) are kept in place during assembly.
3. Place the spring in actuator as per required spring set (see Figure 34).
4. Put the end cap screw washer (10) on the end cap screw (9) and tighten each end cap screw in small equal turns and in the sequence as per Figure 35.

Refer to Table 15 for the correct torque. We recommend to use some grease on the screws for easier fastening.

### END CAPS REASSEMBLY - SPRING-RETURN (SIZES 0950 TO 4000)

FIGURE 35




### 9.6 BASIC FUNCTION AND AIR LEAK TEST

1. Apply pressure (max. 8 bar/120 psi) to ports A and B. Use some soap suds at the indicated points: around pinion top (1), pinion bottom (2), the end caps (3) and limit stops (4).
2. In case of leakage around:
  - a. The limit stop bolts: Turn the lock nut of the bolts tighter, until the leakage stops.
  - b. The end caps: Disassemble the end caps, replace o-rings and reassemble.
  - c. The pinion top or bottom and A- or B- port: Disassemble the complete actuator, replace o-rings and reassemble.

**⚠ CAUTION - MOVING PARTS ⚠**  
Applying pressure to the actuator will cause the actuator/valve assembly to operate.

### BASIC FUNCTION AND AIR LEAK TEST

FIGURE 36



### 10.1 MECHANICAL PROBLEMS

| PROBLEM  | POSSIBLE ERROR  | SOLUTION  | WHERE TO FIND |
|--|---|---|---------------|
| Feedback position and actual position are not the same.                                  | Actuator and valve are mounted 90° rotated in relation to each other. | Remove actuator from valve. Check assembly code of actuator. Put both valve and actuator in "Closed" position. Mount actuator on valve. | Section 4     |
| Valve is in "Closed" position, actuator is in "Open" position and will not move anymore. |   |   |               |
| Valve does not reach the completely "Closed" or "Open" position.                         | Limit stop screws are not set correctly.                              | Readjust the limit stop screws.   | Section 5     |
|  | Insert is not mounted properly.                                       | Mount the insert in the right position.<br>Remark: Rotate insert to one cam = 22.5°.  | Section 4.5   |
|  | Pressure too low.   | Apply pressure as per sizing.   |               |
|  | Sizing is wrong.  | Check valve torque data with actuator torque data.  |               |
|  | Pinion is mounted in the wrong position.                              | Re-assemble actuator.   | Section 9     |
| Actuator rotates, valve does not.  | No coupling between actuator shaft and valve spindle.                 | Install a coupling between actuator shaft and valve spindle.  | Section 4.5   |
| Actuator does not rotate or does not rotate smoothly.                                    | Broken gearing on pistons or pinion.                                  | Contact Apollo representative to replace actuator.  | Appendix A.   |
|  | Spring or Spring cartridge is broken.                                 | Contact Apollo representative to replace actuator.  |               |
| Limit stop screws cannot be turned out anymore.  | Limit stop screws is bend.  | Contact Apollo representative to replace actuator.  |               |

### 10.2 PNEUMATIC PROBLEMS

| PROBLEM  | POSSIBLE ERROR  | SOLUTION  | WHERE TO FIND  |
|--|---|---|--|
| Actuator does not react to electrical control signal.      | There is no supply pressure at the actuator.                                  | Supply the right pressure to the actuator.  | Section 2.3<br>Check that the actual supply pressure is higher than the sizing pressure. |
| Actuator does not react good to electrical control signal. | There is sufficient supply air pressure but insufficient supply air capacity. | Take care the supply air tubing has the right dimensions.   | Section 4.6  |
|  | Supply pressure too low, causing pilot operated solenoid valve to fail.       | Check that supply pressure at the actuator and solenoid is sufficient to operate the actuator.                        | Section 2.3<br>Check that the actual supply pressure is higher than the sizing pressure. |
|  | Solenoid valve is not mounted properly.                                       | Check the solenoid valve mounting.  | Instructions shipped with the solenoid valve.  |
|  | Speed control throttle (if present) blocks air flow.                          | Turn the speed control more open.   | Instructions shipped with the speed control valve.                                       |
|  | Manual override (if present) on the Solenoid Valve is locked.                 | Unlock manual override on the solenoid valve.   | Instructions shipped with the manual override.   |
| Air leakage between actuator and solenoid valve.           | Sealing between solenoid valve and actuator is not mounted air tight.         | Reassemble solenoid valve taking care, that all seals are in place.   | Instructions shipped with the solenoid valve.  |
| Double-acting actuator will only move to "open" position.  | Actuator has wrong solenoid valve configuration.                              | Mount a solenoid valve suitable for double-acting actuators (4/2 or 5/2 function).                                    | Instructions shipped with the solenoid valve.  |
|  |   | Check that conversion plate on solenoids, that have both 3/2 and 5/2 functions, is in the right position.             | Instructions shipped with the solenoid valve.  |
| Leakage notice on the actuator.                            | Seals on the limit stops screws are not air tight.                            | Turn the lock nut of the bolts tighter; until the leakage stops.  | Section 9.6  |
|  | Seals on the end caps are not air tight.                                      | Disassemble the end caps, replace O-rings and reassemble. Consider to replace all O-ring seals and bearings.          | Section 9.6 or Section 6   |
|  | Seals on the pinion top and bottom are not air tight.                         | Disassemble the complete actuator, replace O-rings and reassemble. Consider to replace all O-ring seals and bearings. | Section 9.6 or Section 6   |


### 10.3 ELECTRICAL PROBLEMS

| PROBLEM   | POSSIBLE ERROR   | SOLUTION                                      | WHERE TO FIND  |
|---|--|---|--|
| Actuator does not react to control signals.   | Control wiring. Power supply wiring or feedback wiring are not right connected.                  | Connect all wiring in the right way.          | Instructions of the control or feedback accessories. |
|   | The power supply voltage is not is not the same as the voltage of the applicable solenoid valve. | Connect the right power supply voltage.       | Instructions of the solenoid valve.                  |
| There are problems with position feedback after sending the actuator to either the "Open" or "Closed" position. | The wiring of the feedback signals may be switched.  | Connect the feedback wiring in the right way. | Instructions of the feedback device.                 |

# AD/AD ACTUATOR IOM

## SECTION 11 - PARTS LISTS

### 11.1 ACTUATOR SIZE 0012



#### PARTS LIST SIZE 0012

| POS. | QTY    | NOTES | DESCRIPTION           | MATERIAL                    |
|------|--------|-------|-----------------------|-----------------------------|
| 1    | 1      |       | House                 | Extruded aluminium alloy    |
| 2    | 2      | 1     | B-port ball           | Steel                       |
| 5    | 2      |       | End cap SR (DA)       | Cast aluminium alloy        |
| 6    | 2      |       | End cap DA            | Cast aluminium alloy        |
| 7    | Max. 2 |       | Springs               | Spring steel                |
| 8    | 8      |       | End cap screw DA      | Stainless steel             |
| 9    | 8      |       | End cap screw SR      | Stainless steel             |
| 11   | 2      | 1     | O-ring end cap        | Nitrile rubber              |
| 12   | 2      |       | Warning sticker DA    | Polyester                   |
| 13   | 2      |       | Warning sticker SR    | Polyester                   |
| 14   | 2      |       | Piston                | Cast aluminium alloy        |
| 15   | 2      | 1     | Bearing piston        | PTFE 25% carbon-filled      |
| 16   | 2      | 1     | O-ring piston         | Nitrile rubber              |
| 17   | 1      | 1     | Guide band            | Nylatron                    |
| 18   | 2      |       | Pinion                | High grade aluminium        |
| 19   | 1      | 1     | Bearing pinion top    | POM                         |
| 20   | 1      | 1     | Bearing pinion bottom | POM                         |
| 21   | 1      | 1     | O-ring pinion top     | Nitrile rubber              |
| 22   | 1      | 1     | O-ring pinion bottom  | Nitrile rubber              |
| 23   | 1      | 1     | Thrust bearing pinion | POM, black UV stabilized    |
| 26   | 1      |       | Indicator assembly    | ABS + stainless steel screw |
| 27   | 1      | 1     | Circlip               | Spring steel                |


Notes:

1. Included in service kit.

# AD/AD ACTUATOR IOM

## SECTION 11 - PARTS LISTS

### 11.2 ACTUATOR SIZES 0025 TO 0600



#### PARTS LIST SIZES 0025 TO 0600

| POS. | QTY     | NOTES | DESCRIPTION               | MATERIAL                    |
|------|---------|-------|---------------------------|-----------------------------|
| 1    | 1       |       | House                     | Cast aluminium alloy        |
| 2    | 2       | 1     | B-port seal               | Nitrile rubber              |
| 3    | 1       |       | Center plate (option)     | Nylon PA6, Black            |
| 5    | 2       | 2     | End cap SR (DA)           | Cast aluminium alloy        |
| 6    | 2       | 2     | End cap DA                | Cast aluminium alloy        |
| 7    | Max. 12 |       | Spring cartridge          | Spring steel                |
| 8    | 8       |       | End cap screw DA          | Stainless steel             |
| 9    | 8       |       | End cap screw SR          | Stainless steel             |
| 10   | 8       |       | End cap screw washer      | Stainless steel             |
| 11   | 2       | 1     | O-ring end cap            | Nitrile rubber              |
| 12   | 2       |       | Warning sticker DA        | Polyester                   |
| 13   | 2       |       | Warning sticker SR        | Polyester                   |
| 14   | 2       |       | Piston                    | Cast aluminium alloy        |
| 15   | 2       | 1     | Bearing piston            | PTFE 25% carbon-filled      |
| 16   | 2       | 1     | O-ring piston             | Nitrile rubber              |
| 17   | 2       | 1     | Bearing strip piston rack | POM                         |
| 18   | 2       |       | Pinion                    | High grade aluminium        |
| 19   | 2       | 1     | Bearing pinion            | POM                         |
| 21   | 2       | 1     | O-ring pinion             | Nitrile rubber              |
| 23   | 1       | 1     | Thrust bearing pinion     | POM, black UV stabilized    |
| 26   | 1       |       | Indicator assembly        | ABS + stainless steel screw |
| 27   | 1       | 1     | Circlip                   | Spring steel                |
| 28   | 1       |       | Drive insert              | Aluminium                   |
| 30   | 2       |       | Limit stop screw          | Stainless steel             |
| 31   | 2       |       | Limit stop nut            | Stainless steel             |
| 32   | 2       | 1     | Limit stop washer         | PA66                        |
| 33   | 2       | 1     | O-ring limit stop         | Nitrile rubber              |


**Notes:**

- Included in service kit.
- Actuator sizes 0025 to 00100 have high end caps for double-acting and spring-return models.  
Actuator sizes 0150 to 4000 have low end caps for double-acting models and high end caps for spring-return models.

# AD/AD ACTUATOR IOM

## SECTION 11 - PARTS LISTS

### 11.3 ACTUATOR SIZES 0950 TO 2500




#### PARTS LIST SIZES 0950 TO 2500

| POS. | QTY    | NOTES | DESCRIPTION               | MATERIAL                    |
|------|--------|-------|---------------------------|-----------------------------|
| 1    | 1      |       | House                     | Cast aluminium alloy        |
| 2    | 2      | 1     | B-port seal               | Nitrile rubber              |
| 3    | 1      |       | Center plate (option)     | Nylon PA6, Black            |
| 4    | 12     |       | Thread insert             | Steel                       |
| 5    | 2      |       | End cap SR                | Cast aluminium alloy        |
| 6    | 2      |       | End cap DA                | Cast aluminium alloy        |
| 7    | Max. 6 |       | Springs                   | Spring steel                |
| 8    | 12     |       | End cap screw DA          | Stainless steel             |
| 9    | 12     |       | End cap screw SR          | Stainless steel             |
| 10   | 12     |       | End cap screw washer      | Stainless steel             |
| 11   | 2      | 1     | O-ring end cap            | Nitrile rubber              |
| 12   | 2      |       | Warning sticker DA        | Polyester                   |
| 13   | 2      |       | Warning sticker SR        | Polyester                   |
| 14   | 2      |       | Piston                    | Cast aluminium alloy        |
| 15   | 2      | 1     | Bearing piston            | PTFE 25% carbon-filled      |
| 16   | 2      | 1     | O-ring piston             | Nitrile rubber              |
| 17   | 2      | 1     | Bearing strip piston rack | POM                         |
| 18   | 1      |       | Pinion                    | High grade aluminium        |
| 19   | 2      | 1     | Bearing pinion top        | POM                         |
| 20   | 1      | 1     | Bearing pinion bottom     | POM                         |
| 21   | 1      | 1     | O-ring pinion top         | Nitrile rubber              |
| 22   | 1      | 1     | O-ring pinion bottom      | Nitrile rubber              |
| 23   | 1      | 1     | Thrust bearing pinion     | POM, black UV stabilized    |
| 26   | 1      |       | Indicator assembly        | ABS + stainless steel screw |
| 27   | 1      | 1     | Circlip                   | Spring steel                |
| 28   | 1      |       | Drive insert              | Aluminium                   |
| 29   | 1      | 1     | Backup ring               | POM                         |
| 30   | 2      |       | Limit stop screw          | Stainless steel             |
| 31   | 2      |       | Limit stop nut            | Stainless steel             |
| 32   | 2      | 1     | Limit stop washer         | PA66                        |
| 33   | 2      | 1     | O-ring limit stop         | Nitrile rubber              |

**Notes:**

- Included in service kit.
- Actuator sizes 0025 to 00100 have high end caps for double-acting and spring-return models.  
Actuator sizes 0150 to 4000 have low end caps for double-acting models and high end caps for spring-return models.

### 11.4 ACTUATOR SIZE 4000



#### PARTS LIST SIZE 4000

| POS. | QTY    | NOTES | DESCRIPTION               | MATERIAL                    |
|------|--------|-------|---------------------------|-----------------------------|
| 1    | 1      |       | House                     | Cast aluminium alloy        |
| 2    | 2      | 1     | B-port seal               | Nitrile rubber              |
| 3    | 1      |       | Center plate (option)     | Nylon PA6, Black            |
| 4    | 12     |       | Thread insert             | Steel                       |
| 5    | 2      |       | End cap SR                | Cast aluminium alloy        |
| 6    | 2      |       | End cap DA                | Cast aluminium alloy        |
| 7    | Max. 6 |       | Springs                   | Spring steel                |
| 8    | 12     |       | End cap screw DA          | Stainless steel             |
| 9    | 12     |       | End cap screw SR          | Stainless steel             |
| 10   | 12     |       | End cap screw washer      | Stainless steel             |
| 11   | 2      | 1     | O-ring end cap            | Nitrile rubber              |
| 12   | 2      |       | Warning sticker DA        | Polyester                   |
| 13   | 2      |       | Warning sticker SR        | Polyester                   |
| 14   | 2      |       | Piston                    | Cast aluminium alloy        |
| 15   | 2      | 1     | Bearing piston            | PTFE 25% carbon-filled      |
| 16   | 2      | 1     | O-ring piston             | Nitrile rubber              |
| 17   | 2      | 1     | Bearing strip piston rack | POM                         |
| 18   | 1      |       | Pinion                    | High grade aluminium        |
| 19   | 2      | 1     | Bearing pinion top        | POM                         |
| 20   | 1      | 1     | Bearing pinion bottom     | POM                         |
| 21   | 1      | 1     | O-ring pinion top         | Nitrile rubber              |
| 22   | 1      | 1     | O-ring pinion bottom      | Nitrile rubber              |
| 23   | 1      | 1     | Thrust bearing pinion     | POM, black UV stabilized    |
| 26   | 1      |       | Indicator assembly        | ABS + stainless steel screw |
| 27   | 1      | 1     | Circlip                   | Spring steel                |
| 28   | 1      |       | Drive insert              | Aluminium                   |
| 29   | 1      | 1     | Backup ring               | POM                         |
| 30   | 2      |       | Limit stop screw          | Stainless steel             |
| 31   | 2      |       | Limit stop nut            | Stainless steel             |
| 32   | 2      | 1     | Limit stop washer         | PA66                        |
| 33   | 2      | 1     | O-ring limit stop         | Nitrile rubber              |

Notes:

1. Included in service kit.

This section explains:

How to remove the spring load safely of spring-return actuators in case:

- The valve gets “stuck” in mid position.
- One of the spring cartridges is broken.

**⚠ CAUTION - MOVING PARTS ⚠**

A spring-return actuator mounted on a valve, which is stuck in mid stroke, contains a high spring load which will cause a sudden rotation of the actuator versus the valve during disassembly. This can cause serious injury to personnel or damage to material.

On spring-return actuators with a broken spring cartridge, the end cap can be “shot” away during disassembly of the actuator. This can cause serious injury to personnel or damage to material.

### A.1 SPRING LOAD RELIEF



**⚠ CAUTION - ROTATING ACTUATOR ⚠**

A spring-return actuator mounted on a valve, which is stuck in mid stroke, contains a high spring load which will cause a sudden rotation of the actuator versus the valve during disassembly. This can cause serious injury to personnel or damage to material.

On spring-return actuators with a broken spring cartridge, the end cap can be “shot” away during disassembly of the actuator. This can cause serious injury to personnel or damage to material.

### SPRING LOAD REMOVAL

FIGURE A-1



1. Depressurize the actuator completely.
2. Based on the actuator size, choose the correct threaded rod kit from Table A-1.
3. Replace one by one each end cap screw for the threaded rod kit and turn down the adjusting nut until it touches the end cap.
4. Once all for end cap screws have been replaced, gradually turn the adjustment nuts on threaded rod in CCW direction by turning the nuts half turn at a time. Make sure the rod itself does not turn. Continue this until the load of springs are relieved.
5. Repeat the same procedure for the end cap screws on the other size of the actuator as shown in figure A-1.
6. In case of an actuator/valve assembly “stuck” in mid position: The actuator now can be disassembled from Valve, by removing the mounting studs/bolts.


### THREAD ROD DIMENSIONS (MM)

TABLE A-1

| ACTUATOR SIZE | THREAD | THREADED ROD LENGTH |        |
|---------------|--------|---------------------|--------|
|               |        | (MM)                | (INCH) |
| 0012          | M4     | 132                 | 5.2    |
| 0025          | M5     | 140                 | 5.5    |
| 0040          | M5     | 140                 | 5.5    |
| 0065          | M5     | 140                 | 5.5    |
| 0100          | M5     | 140                 | 5.5    |
| 0150          | M6     | 145                 | 5.7    |
| 0200          | M6     | 145                 | 5.7    |
| 0350          | M8     | 185                 | 7.3    |
| 0600          | M10    | 185                 | 7.3    |
| 0950          | M12    | 498                 | 19.6   |
| 1600          | M12    | 498                 | 19.6   |
| 2500          | M12    | 498                 | 19.6   |
| 4000          | M14    | 600                 | 23.6   |

### SPRING LOAD REMOVAL ROD DIMENSIONS

FIGURE A-2



This section explains:

- Which tools to use for the indicated fasteners.
- The recommended amount of torque to apply on the indicated fasteners.

### END CAP SCREW TORQUE

TABLE B-1

| ACTUATOR SIZE | THREAD | TOOL      | SIZE | TORQUE (NM) |      |      | TORQUE (LB.FT) |      |      |
|---------------|--------|-----------|------|-------------|------|------|----------------|------|------|
|               |        |           |      | TARGET      | MIN. | MAX. | TARGET         | MIN. | MAX. |
| 0012          | M4     | Allen key | SW 3 | 1.1         | 0.8  | 1.3  | 0.8            | 0.6  | 1.0  |
| 0025          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0040          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0065          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0100          | M5     |           | SW 4 | 2.0         | 1.6  | 3.0  | 1.5            | 1.2  | 2.2  |
| 0150          | M6     |           | SW 5 | 3.3         | 2.6  | 5.1  | 2.4            | 1.9  | 3.8  |
| 0200          | M6     |           | SW 5 | 3.3         | 2.6  | 5.1  | 2.4            | 1.9  | 3.8  |
| 0350          | M8     |           | SW 6 | 8.4         | 6.7  | 12.2 | 6.2            | 4.9  | 9.0  |
| 0600          | M10    |           | SW 8 | 15.3        | 12.2 | 24.8 | 11.3           | 9.0  | 18.3 |
| 0950          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 1600          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 2500          | M12    |           | SW10 | 24.3        | 19.4 | 41.6 | 17.9           | 14.3 | 30.7 |
| 4000          | M14    |           | SW12 | 43.5        | 34.8 | 66.4 | 32.1           | 25.7 | 49.0 |

### BOTTOM FLANGE

TABLE B-2

| ACTUATOR SIZE    | ISO PATTERN        | IMPERIAL THREAD | TORQUE (LB.FT) |       |
|------------------|--------------------|-----------------|----------------|-------|
|                  |                    |                 | MIN.           | MAX.  |
| 0012             | F04                | 10-24UNC        | 3.3            | 3.7   |
| 0025             | F03 inner pattern  | 10-24UNC        | 1.5            | 2.2   |
|                  | F05 outer pattern  | 1/4"-20         | 3.3            | 3.7   |
| 0040, 0065, 0100 | F05 inner pattern  | 1/4"-20         | 3.3            | 3.7   |
|                  | F07 outer pattern  | 5/16"-18        | 7.7            | 9.2   |
| 0150, 0200, 0350 | F07 inner pattern  | 5/16"-18        | 7.7            | 9.2   |
|                  | F10 outer pattern  | 3/8"-16         | 15.5           | 18.1  |
| 0600             | F10 inner pattern  | 3/8"-16         | 15.5           | 18.1  |
|                  | F12 outer pattern  | 1/2"-13         | 25.4           | 31.7  |
| 0950             | F10 inner pattern  | 3/8"-16         | 15.5           | 18.1  |
|                  | F14 outer pattern  | 5/8"-11         | 66.4           | 76.7  |
| 1600, 2500       | F16 inner pattern  | 3/4"-10         | 125.4          | 150.5 |
|                  | F25* outer pattern | 4x 5/8"-11      | 66.4           | 76.7  |
| 4000             | F16 inner pattern  | 3/4"-10         | 125.4          | 150.5 |
|                  | F25 outer pattern  | 8x 5/8"-11      | 66.4           | 76.7  |

Sizes 1600 and 2500: Only 4 holes of the ISO5211 F25 drilling pattern are available.

### NAMUR (VDE/VDI 3845) FLANGES

TABLE B-3

| FLANGE                        | IMPERIAL THREAD | TORQUE (LB.FT) |      |
|-------------------------------|-----------------|----------------|------|
|                               |                 | MIN.           | MAX. |
| Solenoid flange screw threads | 10-24UNC        | 1.5            | 2.2  |
| Top flange screw threads      | 10-24UNC        | 1.5            | 2.2  |

### LIMIT STOP DIMENSIONS

TABLE B-4

| ACTUATOR SIZE | THREAD | BOLT WRENCH            | NUT WRENCH             |
|---------------|--------|------------------------|------------------------|
|               |        | SIZE (MM)              | SIZE (MM)              |
| 0025          | M 6    | 10                     | 10                     |
| 0040          | M 8    | 13                     | 13                     |
| 0065          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0100          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0150          | M 10   | 17 (16) <sup>1,2</sup> | 17 (16) <sup>1,2</sup> |
| 0200          | M 12   | 19 (18) <sup>1,2</sup> | 19 (18) <sup>1,2</sup> |
| 0350          | M 16   | 24                     | 24                     |
| 0600          | M 20   | 30                     | 30                     |
| 0950          | M 22   | 12                     | 32                     |
| 1600          | M 24   | 14                     | 36                     |
| 2500          | M 27   | 17                     | 41                     |
| 4000          | M 22   | 12                     | 32                     |

1. Default dimension according DIN933 standard.

2. Dimensions in brackets according ISO4017 standard.

3. Actuator size 0012 is not available with limit stops.

### RECOMMENDED CIRCLIP PLIERS ACCORDING DIN 5254 (OR EQUAL) FOR SHAFT CIRCLIPS

TABLE B-5

| ACTUATOR SIZE | PINION TOP DIAMETER | PLIERS ACCORDING DIN 5254 | ACTUATOR SIZE | PINION TOP DIAMETER | PLIERS ACCORDING DIN 5254 |       |    |
|---------------|---------------------|---------------------------|---------------|---------------------|---------------------------|-------|----|
| 0012          | 16 mm               | 0.630"                    | A1            |                     |                           |       |    |
| 0025 - 0100   | 22 mm               | 0.866"                    | A2            | 0950                | 65 mm                     | 2.559 | A3 |
| 00150 - 0350  | 36 mm               | 1.417"                    | A3            | 1600                | 75 mm                     | 2.953 | A3 |
| 0600          | 55 mm               | 2.165"                    | A3            | 2500                | 95 mm                     | 3.74  | A4 |
|               |                     |                           |               | 4000                | 96 mm                     | 3.78  | A4 |

### ANGULAR DISPLACEMENT LIMIT STOP

TABLE B-6

| ACTUATOR SIZE | TURNS FOR 5° ADJUSTMENT OF THE PINION                | 360° REVOLUTION OF LIMIT STOP SCREW WILL ADJUST | ACTUATOR SIZE | TURNS FOR 5° ADJUSTMENT OF THE PINION | 360° REVOLUTION OF LIMIT STOP SCREW WILL ADJUST |
|---------------|--|---|---------------|---------------------------------------|---|
| 0012          | Actuator size 0012 is not available with limit stops |   | 0350          | 0.8                                   | 6.3°  |
| 0025          | 0.7  | 7.1°  | 0600          | 0.8                                   | 6.3°  |
| 0040          | 0.8  | 6.3°  | 0950          | 1.1                                   | 4.7°  |
| 0065          | 0.6  | 8.3°  | 1600          | 1.3                                   | 4.1°  |
| 0100          | 0.7  | 7.1°  | 2500          | 1.5                                   | 3.4°  |
| 0150          | 1.2  | 4.2°  | 4000          | 3.2                                   | 1.6°  |
| 0200          | 1.0  | 5.0°  |               |                                       |   |

This section explains:

This section explains:

- How to mount the Full Stroke Adjustment option to an actuator
- How to adjust the Full Stroke Adjustment option to a required rotation angle.


### C.1 FULL STROKE ADJUSTMENT OPTION

The Full Stroke Adjustment option is available as a complete actuator or as an end cap conversion kit in order to upgrade a standard actuator into a Full Stroke Adjustment version.

The option is available for sizes 0025 to 0600 and both the double acting kit and spring return kit use the spring return end cap.

#### AVAILABILITY FORMATS OF THE FULL STROKE ADJUSTMENT OPTION

FIGURE C-1




### C.2 CONVERT A STANDARD ACTUATOR INTO A FULL STROKE ADJUSTMENT VERSION

Before starting to assemble the Full Stroke adjustment kit, please check the kit for completeness. See figure C-2.

#### FULL STROKE ADJUSTMENT KIT CONTENTS

FIGURE C-2



#### FULL STROKE ADJUSTMENT KIT CONTENTS

TABLE C-1

| POS. | QTY | NOTES | DESCRIPTION                               | MATERIAL             |
|------|-----|-------|---|----------------------|
| 40   | 2   | 1     | End cap - Full stroke adjustment          | Cast aluminium alloy |
| 41   | 2   |       | Full Stroke adjustment screw              | Stainless steel      |
| 42   | 2   |       | Full Stroke adjustment Nut                | Stainless steel      |
| 43   | 2   |       | Full Stroke adjustment washer             | PA66                 |
| 44   | 2   |       | O-Ring - Full Stroke adjustment screw     | Nitrile rubber       |
| 45   | 2   |       | O-Ring - Thread bush                      | Nitrile rubber       |
| 46   | 2   |       | Thread bush                               | Aluminium            |
| 9    | 8   |       | End cap screw                             | Stainless steel      |
| 10   | 8   |       | Washer end cap screw                      | Stainless steel      |
| 11   | 2   |       | O-ring end cap                            | Nitrile rubber       |
| 12   | 2   |       | Warning sticker DA Full Stroke adjustment | Polyester            |
| 13   | 2   |       | Warning sticker SR Full Stroke adjustment | Polyester            |

Notes:

- The same full stroke adjustment end cap is used for both double acting and spring return actuators (flat double acting actuator end caps with full stroke adjustment options are not available).

# AD/AD ACTUATOR IOM

## APPENDIX C - FULL STROKE ADJUSTMENT OPTION

### C.2.1 PROCEDURE


1. Remove the existing end caps of a standard actuator.
  - Follow the instructions of Section 8 to remove both the end caps of the actuator.
  - For spring return actuators; note the original positions of the spring cartridges.
2. Mount the Full Stroke Adjustment End cap kit to the actuator.
  - The stroke adjustment screw (41) is factory set at the 90° position.
3. Grease the O-ring seals (11) and B port seals (2) according to section 9.1.
4. Ensure that O-ring seals (11) and B port seals (2) are kept in place during assembly.
5. For spring return actuators; place the spring cartridges (7) back in their original positions.
6. Install the Full Stroke end cap kits and tighten the end cap screws (9,10). For spring return units; tighten each end cap screw (9,10) in small equal turns and in the sequence as per Figure C-3.

Refer to Appendix B, Table B-1 for the correct torque.

7. For Spring Return units, place the black warning sticker (13) on the end cap. For Double Acting units, place the white warning sticker (12) on the end cap.

### ASSEMBLY OF FULL STROKE ADJUSTMENT END CAP KIT

FIGURE C-3



### C.3 FULL STROKE ADJUSTMENT SETTING

**NOTICE**

Standard actuators or actuators with the Full Stroke Adjustment option are shipped by default with a rotation setting of 90° +/-0.5°.

The stroke adjustment setting procedure can be two steps:

1. Setting the Full Stroke Adjustment screw to the 90° (factory) position.
  - This step can be applicable if a standard actuator needs to be converted with a Full Stroke Adjustment end cap kit or if the position of the Full Stroke Adjustment screw is somehow lost.
2. Setting the Full Stroke Adjustment screw to the required angle.


#### C.3.1 FACTORY SETTING PROCEDURE

1. In order to set the Full Stroke Adjustment Screws accurately to the outward position:
  - Do not change the setting of the DSA limit stop screws (A and B) located above the air connection interface.
  - Move the pistons of the actuator outwards by applying pressure to the A-port.
2. Screw in both the Full Stroke Adjustment Screws (41) until the screws touch the pistons. You will feel an obstruction.
 

**Important: Do not overtighten the screws.**

#### DSA LIMIT STOP SCREW SETTING

FIGURE C-4



You have now set the adjustment screw to the factory setting

Notes:

1. Only the outward stroke can be adjusted with the Full Stroke Adjustment screws.
  - In case of assembly code CW, the left side limit stop (A) is redundant.
  - In case of assembly code CC, the right side limit stop (B) is redundant.
2. For the inward stroke the standard limit stops can be used:
  - The right side limit stop (B) for assembly code CW
  - The left side limit stop (A) for assembly code CC

### C.3.2 SETTING THE FULL STROKE ADJUSTMENT SCREW TO THE REQUIRED ANGLE.

1. Move the pistons of the actuator inwards.
  - For Spring Return actuators this happens automatically when the actuator is vented.
  - For double acting actuators vent the A-port and apply pressure to the B-port.
2. In order to set the actuator to the required angle, use next table to define the number of revolutions which you have to turn in the Full Stroke Adjustment Screws.
3. Turn in both the adjustment screws (41) as defined in step 2. Both the adjustment screws should be turned in with the same length or number of revolutions.

**⚠ CAUTION - DO NOT SET SCREWS UN-EQUAL ⚠**

Screwing in only one adjustment screw or un-equal setting of both the screws will lead to high point loads on the pistons and can cause premature failure of the actuator.

4. Test cycle the actuator to check if the correct rotation angle is set. If required, repeat steps 1 to 3 to adjust the rotation angle to the required angle.

**ACTUATOR ANGLE ROTATION PER FULL REVOLUTION OF FULL STROKE ADJUSTMENT SCREW**  
TABLE C-2

| ACTUATOR SIZE | STROKE |      | FLATHEAD SCREW DRIVER | SCREW  |            | ACTUATOR ANGLE ROTATION PER FULL REVOLUTION OF SCREW |
|---------------|--------|------|-----------------------|--------|------------|--|
|               | MM     | INCH |                       | THREAD | PITCH (MM) |  |
| 0025          | 15.7   | 0.62 | 1.0 x 5.5             | M6     | 1          | 5.7°   |
| 0040          | 18.8   | 0.74 | 1.2 x 6.5             | M8     | 1.25       | 6.0°   |
| 0065          | 22.0   | 0.87 | 1.2 x 6.5             | M8     | 1.25       | 5.1°   |
| 0100          | 25.1   | 0.99 | 1.2 x 6.5             | M10    | 1.5        | 5.4°   |
| 0150          | 31.4   | 1.24 | 1.2 x 6.5             | M10    | 1.5        | 4.3°   |
| 0200          | 37.7   | 1.48 | 1.2 x 6.5             | M10    | 1.5        | 3.6°   |
| 0350          | 37.7   | 1.48 | 1.2 x 6.5             | M12    | 1.75       | 4.2°   |
| 0600          | 44.0   | 1.73 | 1.2 x 6.5             | M16    | 2          | 4.1°   |